

Instructions

Charging & Synchronising
Compact TabCabby Units



TabCabby with GO2 Mini - 20V

To UNLOCK front doors – turn the key on the top of the unit and then rotate the camlock wing control 90° anticlockwise (top view photo of the lock with the directions on it). (See Fig. 1)

To UNLOCK rear door – pull the handle towards you, located inside underneath the top panel. (See Fig. 2)

To UNLOCK side doors – push down the latch located on the side of the unit at the front. (See Fig. 3)

To LOCK the unit – close the rear door first, then the side doors, close the front door on the unit rotate the camlock wing control 90° clockwise and turn the key.



To install tablets or iPads into TabCabby:

1. Pull the shelf out and place tablets into the GO2 mini baskets (5 tablets per basket).
2. Plug the cables into the USB hubs, thread the cables through the cable ports in the rear of the unit, and push into clips to secure.
3. Plug power cables into your devices and adjust cable length so the drawer can be opened.
4. Finally plug the provided LapCabby mains lead into the IEC socket located on the side panel and then into your mains to power up the unit.

TabCabby Compact Series - 16HC 32HC

To UNLOCK front doors – turn the key on the top of the unit and then rotate the camlock wing control 90° anticlockwise (top view photo of the lock with the directions on it). (See Fig. 4)

To UNLOCK side doors – push down the latch located on the side of the unit at the front. (See Fig. 5)

To LOCK the unit – close the side doors then close the front door, on the unit rotate the camlock wing control 90° clockwise and turn the key.



To install tablets or iPads into TabCabby:

1. Place your devices on to the fixed shelves (2 tablets/iPads per tray for 32HC & 1 tablet/iPad per tray for 16HC).
2. Plug in cables into the USB hub, thread the cables through the cable ports in the side of the unit, and push into clips to secure.
3. Plug power cables into your devices.
4. Finally plug the provided LapCabby mains lead into the IEC socket located on the side panel and then into your mains to power up the unit.

Note: Front 2 castors have lockable wheels. Lock when TabCabby is in position by pushing down on the castor foot plate.

User / Setup Guide

Connecting your tablets/iPads to the TabCabby Unit:

The 16 port USB-A or USB-C charge and sync unit is a universal device designed to charge and/or sync applications (apps) on up to 16 compatible USB devices, including tablets and mobile phones. Connect any devices needing charging using your devices USB charging cable. Then simply plug your TabCabby into the power socket with IEC lead and switch on the plug socket. Then switch on the hub which will give power to each of the 16 USB ports (Fig. 1).

When the device is not fully charged the corresponding indicator light will show red (Fig. 2), when the device is fully charged it will go green, the hub will stop charging when the device is fully charged.

Synching applications to devices via the USB hub

Before carrying out the sync process ensure a host computer (i.e. laptop or desktop PC/Mac) has the appropriate sync software. Please contact the device manufacturer for the correct software to use.

Connect your host computer to the USB hub via the front panel USB-B connection port shown (fig. 3), you will need to keep the side door open. Make sure the TabCabby is plugged in and switched on at the mains along with the hub. When connected the hub will switch from charging to synching. Devices connected to the USB hub ports will be visible through the appropriate software on the host computer and the synching process can begin, data transfer rates are up to 480 Mbps. When synching has completed disconnect the host computer from the USB hub, the device will switch from synching back to the charging function. The sync function can be performed at any time if a host computer with the correct software is connected to the USB hub via the correct cable.



General Safety Precautions

There are no servicable parts inside the TabCabby USB hub. The USB hub casings enclose high voltage electrical and electronic components, under no circumstances should the casing be removed, only by trained personnel are allowed access to the inside of the unit.

Under no circumstances should the air vents on the USB hub be covered.

The TabCabby USB hub is designed for re-charging and synching purposes only. This unit is specifically designed for use of tablets and their factory supplied USB cables, Using the hub for recharging or powering any other equipment will invalidate the warranty.

To avoid risk of electric shock or fire the unit should only be used by a competent adult.

This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

The mains power lead must not be pulled when the TabCabby is under power as this could damage critical components. When transporting the TabCabby the mains power lead must be disconnected from the IEC connection socket. Inspect the plug and power lead daily, if the plug and power lead is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons to avoid a hazard.

The TabCabby apparatus should be used in a dry environment and at normal room temperatures. No water or moisture must be allowed in the unit. The TabCabby must not be used outdoors.

Always disconnect the TabCabby from the wall outlet before altering the USB cable configuration or moving the unit.

Before any cleaning of the TabCabby the USB Hub should be switched off and the IEC mains lead must be removed from the mains wall socket. If the tablets are connected to the USB hub these and their factory supplied cables must also be removed. Cleaning of the USB hub should only be done with a dry cloth, no liquid detergents or aerosol cleaners are to be used as these could damage internal components.

Correct disposal of this product:



This marking indicates that this product should not be disposed with other household wastes throughout Australia, Europe and the US. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



DANGER!
RISK OF ELECTRIC SHOCK
DANGER! ELECTRICAL CORDS
CAN BE HAZARDOUS
MISUSE CAN RESULT IN FIRE
OR DEATH BY ELECTRIC SHOCK

Technical Data Sheet

Nature of supply:

Rated mains supply voltage: **UK: 220-240V**
AUS: 230V
Euro: 230V

Rated frequency:

UK: 50Hz
Aus: 50Hz
Euro: 50Hz

Type of power connection:

UK: Detachable mains power lead with UK 3 pin plug and C19 Connector
Aus: Detachable mains power lead with Australian 3 pin plug and C13 Connector (AS/NZS 3112:2004)
Euro: Detachable mains power lead with Schuko type plug and C13 Connector

TabCabby USB Hub

Model: A-165C (USB-C) & A-165 (USB-A)

Input: 100-120V ~, 50/60Hz,4A
200-240V~, 50/60Hz,2A

Output: Maximum total output: 5v =40A, 200W
(each maximum output: 5V=2.1A)

Features:

Over current protection
Over voltage protection
Short circuit protection
LED display port status

Operating Temperature

We recommend an operating temperature of 0°C - 35°C (32°F-95°F)

EQUIPMENT MUST BE SUPPLIED EARTHED / GROUNDED SUPPLY

High Touch current can result from the summation of the touch currents of each of the devices plugged into the unit.

To protect against a hazard the connection to protective earth should be reliable.

The equipment supply connection (mains plug, mains cable and inlet) must be annually inspected / checked for signs defects or excessive wear and replaced where necessary.

