

Instructions

Universal Device Charging
& Storage Units



UniCabby Series - 20H 32H 40H

To Unlock the front door(s) - turn the key on the top of the unit and then rotate the camlock wing control 90° anticlockwise (top view photo of the lock with the directions on it) (Fig. 1).

To unlock the rear door(s) - pull the hidden handle (Fig.2) which is located on the underside of the top in the centre of the unit.

To lock the front door(s) - ensure the back door(s) are securely closed by pushing them shut, the right-hand one first and then left. Then close the front door(s) make sure to close the left-hand door first and then the right-hand door, rotate the camlock wing control 90° clockwise and turn the key.



UniCabby 20H

UniCabby 32H

UniCabby 40H

Note: Front 2 castors have lockable wheels. Lock when UniCabby is in position by pushing down on the castor foot plate.

To install tablets into UniCabby:

1. Plug your device adaptor into the rear of the trolley and place the adaptor block (if needed) into the adaptor tray (Fig. 3).
2. Feed the device cable through the cable port and onto the device tray any excess cables can be tied off on the adaptor tray if required (Fig. 4).
3. Move around to the front of the unit and take the device cables and feed them through the cable valleys, using the clips to secure them into place (Fig. 5).
4. Each tray has 3 cable exit points which can be used to suit the device placed on the tray. Upon exiting the valley, ensure you have enough cable to plug into the device power connection point. The device cable can be clipped into position again by turning the cable clip on the tray.
5. Plug the device cable into the devices on the shelves.
6. Finally plug the provided LapCabby mains lead into the IEC socket located on the side panel and then into your mains to power up the unit (Fig. 6).



UniCabby 20H



UniCabby 32H



UniCabby 40H



Fig. 3



Fig. 4



Fig. 5



Fig. 6

Feed cable through the cable valley



General Safety Precautions

The UniCabby should be situated close to a power socket that is easily accessible. Cabling between the wall and the unit could be a trip hazard.

The UniCabby should never be used on an inclined surface.

Always ensure that all the doors are fully closed and locked and that the mains power lead is disconnected before moving the UniCabby. Forcing the doors beyond 90 degrees will cause damage to the hinges.

The unit is designed for storage and charging purposes only. This unit is specifically designed for use with tablets, Chromebooks and laptops and their factory supplied AC adaptors or USB cables, use for recharging or powering any other equipment will invalidate the warranty.

The brakes on the front two castors should be locked to prevent movement and the doors locked, and the key removed whenever the unit is parked, unattended or charging. Always disconnect the UniCabby mains power lead from the wall outlet before opening the doors or altering the AC adaptor configuration. When the UniCabby is unplugged from the mains wall socket outlet you should ensure the outlet is switched off if possible.

To avoid risk of electric shock or fire the unit should only be used by a competent adult. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

The mains power lead must not be pulled when the UniCabby is under power as this could damage critical components. When moving the UniCabby the mains power lead must be disconnected from the IEC connection socket. Inspect the plug and power lead daily, if the plug and power lead is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons to avoid a hazard.

The UniCabby is intended for indoor use only on carpet, wood or tiled surfaces. Movement across bitumen, tarmac, concrete and rough surfaces should be avoided and doing so will void the warranty claims for damage to the wheels. When moving your UniCabby between floors it is strongly recommended that the unit is transported via a lift or ramp. Do not wheel the UniCabby up or down stairs as this will cause damage to the unit.

The UniCabby should be used in a dry environment and at normal room temperatures. No water or moisture must be allowed into the unit. The UniCabby must not be used outdoors. The UniCabby should not be transported outside unless the weather is warm and dry, if this is unavoidable the unit must be allowed to stand in normal room conditions for at least four hours before it is connected to any laptops or wall sockets.

Before any cleaning of the UniCabby it should be switched off and the IEC mains lead must be removed from the mains wall socket. Cleaning of the unit should only be done with a dry cloth; no liquid detergents or aerosol cleaners are to be used as these could damage internal components.

Technical Data Sheet

Nature of supply:

Rated mains supply voltage: **UK: 220-240V**
Aus: 230V
Euro: 230V

Rated frequency: **UK: 50Hz**
Aus: 50Hz
Euro: 50Hz

Max. current: **Our power strips are rated to 13A.**
Total cumulative Watts requirement of devices in each unit should not exceed 2880W.

Type of power connection:

UK: Detachable mains power lead with UK 3 pin plug and C19 Connector

Aus: Detachable mains power lead with Australia 3 pin plug and C13 Connector (AS/NZS 3112:2004)

Euro: Detachable mains power lead with Schuko type plug and C13 Connector

Operating Temperature:

We recommend an operating temperature of 5°C - 33°C (41°F-91°F). This unit will automatically switch off at 35°C and will switch back on at 29°C, this is to protect the laptop battery.

Cooling condition: Natural convection through vents.

Correct disposal of this product:



This marking indicates that this product should not be disposed with other household wastes throughout the EU, US and Australia. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

EQUIPMENT MUST BE SUPPLIED FROM EARTHED / GROUNDED SUPPLY

High Touch current can result from the summation of the touch currents of each of the devices plugged into the unit.

To protect against a hazard the connection to protective earth should be reliable.

The equipment supply connection (mains plug, mains cable and inlet) must be annually inspected / checked for signs defects or excessive wear and replaced where necessary.



DANGER!
RISK OF ELECTRIC SHOCK
DANGER! ELECTRICAL CORDS
CAN BE HAZARDOUS
MISUSE CAN RESULT IN FIRE
OR DEATH BY ELECTRIC SHOCK

